

# SPECIFICATION



## **SPECIFICATION FOR THE USE OF ROOFCOAT FR10**

1. Remove all organic matter, loose and peeling coatings and roof aggregates (chippings etc). Drains and gutters should be protected against blockage.
2. Clean the surface of any remaining dirt and debris, preferably by suitable high pressure water jetting or stiff bristle brush.
3. Surfaces previously contaminated with moss, lichen and algae growth must be treated with LICHENITE. Apply one coat by brush or spray at a coverage not exceeding 10 square metres per litre. Allow 24 hours before proceeding.
4. Splits, cracks and blisters should be repaired with ROOFCOAT FR10 SCRIM. Apply one coat of ROOFCOAT FR10 to the area to be repaired, cut scrim to the desired length, embed in the wet ROOFCOAT FR10 and apply a second coat. Blisters in felt should be star cut. ROOFCOAT FR10 applied under the flaps and the flaps re-bedded. Strengthen the repair with ROOFCOAT FR10 SCRIM and apply a further coat of ROOFCOAT FR10 over the repair.
5. To the prepared surface apply a generous coat of ROOFCOAT FR10 in selected colour by ROOFCOAT FR10 SPREADER, brush, soft broom or trowel. DO NOT THIN. ROOFCOAT FR10 should be applied at a rate of not less than 1 kg per square metre for flat surfaces. Allow for additional ROOFCOAT FR10 on corrugated or aggregated surfaces. Work away from area immediately being treated and towards a suitable escape exit. Do not walk on the newly coated surface whilst application is in progress or until the coating has cured and dried. Curing time 2-3 days.

## **CLEANING**

Brushes, trowels and spreaders should be cleaned immediately after use in white spirit.

The specification and coverage rates are given in good faith and are based on our experience and knowledge but without liability.

## **IMPORTANT NOTICE**

It is essential that when using any type of chemicals, whether they are disinfectants, washing detergents or mould treatments, that all vulnerable people, children, pets and animals are kept away from the materials and the areas being treated, until they are dry. In addition, any spillage of chemicals must be cleaned up immediately before proceeding further with the work.

Store chemical products in original container, in a safe place away from children and pets.

## **MOULD GROWTH CONSULTANTS LTD**

Unit A3 Longmead Business Centre, Blenheim Road, Epsom, Surrey KT19 9QQ. Tel: 01372 743334